WARNING:

This fixture is intended for installation in accordance with the National Electrical Code (NEC) and all local code specifications. If you are not familiar with code requirements, installation by a certified electrician is recommended.

CAUTION: To prevent shock, only plug in lamp after lamp assembly is complete.

WARNING: This portable lamp has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to work around this safety feature.

Before assembly, remove all parts and part packages from box. If anything is missing, please contact the retailer from which the product was purchased.

- 1. Thread finial (A) onto top of lamp body (B).
- 2. Screw lamp body (B) onto top of tube (C).
- 3. Screw bottom of tube (C) onto top of tube (D).
- 4. Screw bottom of tube (D) onto top of tube (E).
- 5. Slip threaded pipe on bottom of tube (E) through hole in top of base (F). Slip washer (G) over end of threaded pipe protruding from underside of base (F). Screw hex nut (H) onto end of threaded pipe. Using wrench (K), tighten hex nut (H) up against underside of base (F). DO NOT over tighten.
- 6. Insert recommended bulb (not included) into socket. **WARNING:** Verify correct bulb wattage marked on socket of lamp. DO NOT exceed maximum bulb wattage.



M-F 8:00AM-6:00PM ET

ITEM#: D2473

