
**WARNING:** DISCONNECT POWER AT THE MAIN FUSE BOX BEFORE INSTALLATION.

## **WARNING**:

This fixture is intended for installation in accordance with the National Electrical Code (NEC) and all local code specifications. If you are not familiar with code requirements, installation by a certified electrician is recommended.

Before assembly, remove all parts and part packages from box. If anything is missing, please contact the retailer from which the product was purchased.

- 1. Position mounting bracket (A) so threaded ends of attached fixture mounting screws (E) are facing out.
- 2. Carefully pull house wires through large hole in mounting bracket (A).
- 3. Align holes in mounting bracket (A) with holes in junction box.
- 4. Thread each junction box screw (B) into holes in mounting bracket (A) and into holes in junction box. Tighten junction box screws (B) to secure mounting bracket (A) to junction box. CAUTION: Make sure house wires are pulled completely through hole in mounting bracket. DO NOT pinch wires between mounting bracket and wall.




ANY QUESTIONS CALL: 800-613-3261

M-F 8:00AM-6:00PM ET

- 5. Strip 3/4" of insulation from ends of fixture wires.
- 6. Slightly loosen ground screw on mounting bracket (A). Do not completely remove ground screw. Wrap house ground wire (copper) around ground screw, leaving enough ground wire to attach to fixture ground wire. Twist end of fixture ground wire and end of house ground wire together. Twist wire nut (C) onto ends of wires. Completely tighten wire nut (C). Reference chart below for correct wire connections.

Connect Supply (House) Ground Copper Wire to:		
Bare Copper Wire or,		
Bare Silver Wire or,		
Green Insulated Wire.		




elkhome.com

ITEM#: D4387

- 7. Twist end of house lead wire (black) and end of fixture lead wire together. Twist wire nut (C) onto ends of wires. Completely tighten wire nut (C). Twist end of house neutral wire (white) and end of fixture neutral wire together. Twist wire nut (C) onto ends of wires. Completely tighten wire nut (C). Reference chart to the right for correct wire connections.
- 8. Wrap electrical tape (not included) around wire nuts (C) and wires. Ensure wires are securely fastened into wire nuts.
- 9. Carefully push all wires and wire nuts into junction box.

Connect Black Lead Supply (House) Wire to:	Connect White Neutral Supply (House) Wire to:	
Black Wire or,	White Wire or,	
*Parallel Cord (Round and Smooth) or,	*Parallel Cord (Square and Ridged) or,	
No printed words on wire insulation or,	Printed words on wire insulation or,	
Insulated Wire (other than green) with Copper Conductor.	Insulated Wire (other than green) with Silver Conductor.	

\*When parallel wire (SPT 1 & SPT 2) is used: The lead wire is round in shape or smooth. The neutral wire is square in shape or ridged.



- 10. Place backplate (D) over mounting bracket (A). Pass holes in backplate (D) over ends of fixture mounting screws (E). **CAUTION:** Do not pinch wires between backplate and wall.
- 11. Screw one threaded cap (F) onto end of each fixture mounting screw (E). Tighten both threaded caps (F) to secure fixture (D) to wall. DO NOT over tighten.
- 12. Screw recommended bulb (E12 candelabra bulb type, not included) into socket. Verify correct bulb wattage marked on socket of fixture. **WARNING:** DO NOT exceed maximum bulb wattage.
- 13. Place shade (K) over backplate (D). Pass hole in center of shade (K) over end of arm on backplate (D). Thread hexnut (L) onto end of arm protruding from center of shade (K). Tighten hexnut (L) to secure shade (K) in place. DO NOT over tighten.
- 14. Slip cap (M) over end of arm protruding from shade (K). Thread finial (N) onto end of arm protruding from center of cap (M). Tighten finial (N) to secure cap (M) in place. DO NOT over tighten.

