
ASSEMBLY INSTRUCTIONS:

ITEM NO: BO-2450FL

- 1. Carefully unpack and lay out the parts as shown in illustration.
- 2. Screw the Tube (B), (C),(D) and Socket Section(E) into the nipple of Base (A), then pull the cord from base.
- 3. Insert Tube (F) into Socket Section(E).
- 4. Place the Shade (G) onto the Double Stem (F), and tighting it by Finial (H).
- 5. Put Acrylic (I) on Shade(G), then adjust the shade in balance.

(Attention: sand blast side should be downwards)



Your lamp now is ready to enjoy

Use 2*60 Wattage (Maximum) type A bulb (Bulb not included) On-off socket pull-chain switch

IMPORTANT SAFETY INSTRUCTIONS:

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY AND EASILY INSERTED. DO NOT ATTEMPT TO ALTER THE PLUG.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.