


ASSEMBLY INSTRUCTIONS



Candlestick Swing Arm

Item # S2010

WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.

WARNING * SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.**

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

1. Locate the spot where you intend to install the light.
2. Remove the mounting plate (B) from the fixture (A) by removing the side screws (C).
3. Use a level and measuring tape to precisely mark the mounting holes in your wall.
4. Secure the mounting plate to your wall using the appropriate screws. (We have provided drywall anchors and wood screws.)
IT IS IMPERATIVE THAT THE LIGHT BE SECURE TO THE WALL
5. Attach light (A) to mounting plate (B) being careful not to damage the wires.
6. Secure with side screws (C).
7. Install cord cover (D) to light (A) by threading into wire outlet.
8. Thread lower section of cord cover into upper section.
9. Remove finial (E).
10. Remove the silica gel pack from inside socket.
11. Install the appropriate light bulb according to the shade selection guide included.
12. Install lamp shade and secure with finial.
13. Remove plastic cover from power cord plug (F) and plug into outlet.

