
# ASSEMBLY AND INSTALLATION INSTRUCTIONS

P0237

# WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER BEFORE INSTALLING OR SERVICING THIS FIXTURE.

NOTES: 1. Before installing, consult local electrical codes for wiring and grounding requirements 2. READ AND SAVE THESE INSTRUCTIONS.




#### Installation Steps

#### Turn off the power at fuse or circuit box

- Attach two fixture mounting screws to the mounting strap, and then secure it with two lock nuts.
  Adjust the length of the fixture mounting screws if necessary.
- 2. Attach the mounting strap to the outlet box using two mounting screws.
- 3. Rod Connections:
- a. Thread the fixture wire from the fixture through the lower rod, and then secure the lower rod onto fixture sing the threaded pipe.
- b. Thread the fixture wire through the middle rod, and then secure the middle rod onto the lower rod using the threaded pipe.
- c. Thread the fixture wire through the upper rod, and then secure the upper rod onto the middle rod using the threaded pipe.
- d. Thread the fixture wire through the fixture canopy, and then secure fixture canopy onto the upper rod using the threaded pipe.

Note: Length adjustable from 19-1/2'' to 70-1/2''. Use fewer rods if shorter length is desired.

- 4. Pull out the source wires from the outlet box. Make wire connections using wire connectors as follows:
- ---Connect the smooth-coated wire (marked) from the fixture to the black wire from the power source.
- ---Connect the ribbed-coated wire (unmarked) from the fixture to the white wire from the power source.
- ---Attach the fixture grounding wire to the mounting strap with the green grounding screw, and then connect it to the house grounding wire with a wire connector.
  - Carefully put the wires back into the outlet box.
- 5. Screw 12 long rods to the other threaded pipes of fixture.
- 6. Attach the fixture canopy to the mounting strap by inserting the fixture mounting screws, and then secure it with two cylinder nuts.
- 7. Install the bulb (not included).
- Check relamping label at socket area or packaging for maximum allowed wattage.
- 8. Angled mounting recommended for a vaulted or angled ceiling.





## Turn on the power at fuse or circuit box

### The following parts are available for re-order if damaged or missing.

