


# ASSEMBLY INSTRUCTIONS

## ITEM NO: BO-2739DK

1. CAREFULLY UNPACK AND PLACE ALL PARTS ON A SMOOTH SURFACE AND LAY THEM UP AS PER THE SKETCH.
2. LOOSEN THE TURN-KNOB(C) , ADJUST LAMP BODY(A) TO CHANGE HEIGHT.
3. LOOSEN THE TURN-KNOB(D), ADJUST THE SHADE(D), THEN LOCK IT TIGHT.
4. INSERT THE POLARIZED PLUG INTO OUTLET, TURN ON THE SWITCH AND ENJOY YOUR LAMP.



**USE 60 WATTAGE (MAXIMUM) TYPE A BULB (BULB NOT INCLUDED)**

### IMPORTANT SAFETY INSTRUCTIONS:

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG

**SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.**