ITEM NO.: BO-2680TB-2

ASSEMBLY INSTRUCTIONS:

- 1. Carefully unpack parts from carton, remove covering from parts and check that all parts are included as shown in the illustration.
- 2. Insert the harp(C) onto the saddle(E).
- 3. Insert the shade (B) onto the harp (C) and secure it with finial.(A)
- 4. Install the bulb (D) into socket (F).

Use a 25W CFL Type bulb or 150W (Maximum) Incandescent A Type Bulb.

IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

- **** PLEASE INFORM YOUR DEALER IMMEDIATELY IN CASE OF ANY PARTS SHORTAGE.**
- **** SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.**

