

ASSEMBLY INSTRUCTION

L3-1069

- 1.FASTEN SOCKET ASSEMBLY ONTO BASE,BE CAREFUL NOT TO TWIST POWER CORD AND TIGHTEN SECURELY.
- 2.INSERT HARP INTO SADDLE.
- 3.PLACE SHADE ONTO HARP AND TIGHTEN FINIAL.
- 4.PLEASE USE MAX 3 WAY 150W BULB(BULB NOT INCLUDED).

IMPORTANT SAFETY INSTRUCTIONS

THIS PORTABLE LAMP HAS A POLARIZED PLUG(ONE BLADE IS WIDER THAN THE OTHER)AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK.THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY.IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET,REVERSE THE PLUG.IF IT STILL DOES NOT FIT,CONTACT A QUALIFIED ELECTRICIAN.NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED.DO NOT ALTER THE PLUG.

